

1

Sonosシステムを 設定する

Subと使用する予定のSonos製品は、
先に設定を済ませておく必要があります。



2

Subを設置し、 電源を挿し込む



スペースに合わせて縦横どちら
の向きでも設置できます。

3


Subを システムに追加する



Sonosアプリを開き、[設定]
に移動して製品を追加します。

操作ガイド

高音も低音も極め
た臨場感あふれる
サウンドを体験。



カスタマーサポート

カスタマーサポート
sonos.com/support


ユーザーガイド
sonos.com/guides/sub

ご利用規約、使用許諾契約
www.sonos.com/legal/terms-of-use

Terms of Use, License and Warranty
www.sonos.com/legal/terms-of-use

© 2024 Sonos, Inc. All rights reserved. Sonos*,
および Sub は、Sonos, Inc. の商標または登録商標です。
*Sonos は米国特許商標庁登録済みです。

© 2024 Sonos, Inc. All rights reserved. Sonos*, and
Sub are trademarks or registered trademarks of
Sonos, Inc. *Reg. U.S. Pat. & TM Off.



SONOS

セットアップ

English - Set Up

1. **Set up your Sonos system.** Make sure the Sonos product you plan to use with Sub is already set up.
2. **Place Sub on the floor and plug it in.** Standing up or lying flat. Wherever it fits best.
3. **Add Sub to your system.** Open the Sonos app and go to Settings to add a product.
At a glance. Hear higher highs, feel lower lows for a more immersive sound experience.

Sub