

客户支持

sonos.com/support

用户指南

sonos.com/guides/sonosarcultra

帮助

Terms of Use, License and Warranty
www.sonos.com/legal/terms-of-use


© 2024 Sonos, Inc. All rights reserved. Sonos[®] and Sonos Arc are trademarks or registered trademarks of Sonos, Inc. *Reg. U.S. Pat. & TM Off.

使用条款、许可与担保协议
www.sonos.com/legal/terms-of-use

© 2024 Sonos, Inc. 保留所有权利。Sonos[®] 和 Sonos Arc 是 Sonos, Inc. 的商标或注册商标。*Reg. U.S. Pat & TM Off.



610-00200



English – Set Up

1. **Connect the audio and power cables.** Connect the HDMI cable from Sonos Arc Ultra into the ARC or eARC port on your TV and plug in the power cord. Make sure your TV is on.
2. **Download the Sonos app for setup.** Open the Sonos app and go to Settings to add a product.

At a glance. Use WiFi to set up Sonos Arc Ultra. Stream content over WiFi or Bluetooth. **Volume Down** – Slide left (or tap -). **Volume Up** – Slide right (or tap +). **Voice Control** – Tap to turn on or off. **Previous Track, Play/Pause, Next**

Track, Group – Press and hold to group Sonos products. **Microphone Switch** – When it's turned off, all microphone-dependent features including voice control are unavailable. **Bluetooth** – Long press to pair new device; short press to reconnect.

繁體中文 – 設定

1. **連接音訊和電源線。** 將 Sonos Arc Ultra 的 HDMI 線連接至電視的 ARC 或 eARC 埠，然後插入電源線。請確保電視已開啟。
2. **下載 Sonos 應用程式進行設定。** 打開 Sonos 應用程式，前往「設定」以新增產品。

簡介。 使用 Wi-Fi 設置 Sonos Arc Ultra。通過 Wi-Fi 或藍牙流式播放內容。降低音量 – 向左滑動（或輕觸 - 號）。提高音量 – 向右滑動（或輕觸 + 號）。語音控制 – 輕觸以開啟或關閉。上一首曲目。播放 / 暫停。下一首曲目。組合 – 按住可對 Sonos 產品進行分組。麥克風關閉 – 麥克風關閉時，需要麥克風的

功能（包括語音控制服務）將無法使用。藍牙 – 長按配對新裝置；短按重新連接。

Sonos Arc Ultra

設置

01



连接音频线和电源线

将HDMI线缆从Sonos Arc Ultra连接到电视上的ARC或eARC端口，然后插入电源线。确保电视已开机。

注：如果您的电视没有ARC或eARC端口，您可以使用光纤适配器（可在sonos.com上购买）。光纤连接不支持杜比全景声。

02



下载Sonos App进行设置

打开Sonos App，然后转到“设置”，即可添加产品。

概览

使用Wi-Fi设置Sonos Arc Ultra。
通过Wi-Fi或蓝牙流式播放内容。



注：语音控制可能因地理区域不同而异