

1

设置Sonos系统

确保您计划与Sub搭配使用的Sonos产品已设置完毕。



2

将Sub置于地板上并插上电源线



既可竖放，亦可平放。
根据情况灵活选择。

3


将Sub添加至您的系统



打开Sonos App，然后转到
“设置”，即可添加产品。

概览

享受更震撼的高音
和更浑厚的低音，
获得更具沉浸感
的聆听体验。



幫助

客户支持
sonos.com/support

Terms of Use, License and Warranty
www.sonos.com/legal/terms-of-use

© 2024 Sonos, Inc. All rights reserved. Sonos*, and Sub are trademarks or registered trademarks of Sonos, Inc. *Reg. U.S. Pat. & TM Off.



用户指南
sonos.com/guides/sub

使用条款、许可与担保协议
www.sonos.com/legal/terms-of-use

© 2024 Sonos, Inc. 保留所有权利。Sonos*和Sub是Sonos, Inc.的商标或注册商标。*Reg. U.S. Pat. & TM Off.

SONOS

設置

English - Set Up

- Set up your Sonos system.** Make sure the Sonos product you plan to use with Sub is already set up.
- Place Sub on the floor and plug it in.** Standing up or lying flat. Wherever it fits best.
- Add Sub to your system.** Open the Sonos app and go to Settings to add a product.
At a glance. Hear higher highs, feel lower lows for a more immersive sound experience.

繁體中文 - 設定

- 設定你的 Sonos 系統。確保你打算搭配 Sub 使用的 Sonos 產品已設定。
- 將 Sub 置於地面並插入。隨你擺放，可將其直立或水平放置。
- 新增 Sub 至你的系統。打開 Sonos 應用程式，前往「設定」以新增產品。
簡介。高音更高昂，低音更低沉，感受極致樂韻。

Sub